

# STUCCO MARMORINO



Apply one coat of **PRIMER MINERAL** that has been diluted 25% with water. It can be rolled, brushed or sprayed on; Let it dry 6 hours.



Apply first coat of **MARMORINO** with stainless steel trowel, skimmed in all directions, creating soft textured and organic designs. The grain of Primer Mineral must be covered; to avoid chatter marks work with a little bit more material with rounded motions, in all directions. Dry to “in love” or completely.



Apply second layer of **MARMORINO** with stainless trowel, when first coat is “in love” or completely dry. Work in diagonal passes from wet to dry; make sure everything is 100% covered and remove excess material (open the trowel angle slightly). Burnish lightly when still “in love”.



**OPTION:** when second layer is just set (before burnishing), use **VEILCALCE TRANSPARENT** light tinted or white and skim coat it over (non-diluted) with trowel, just to embed a very small amount of lime paint. You also can dilute **VEILCALCE TRANSPARENT** and brush it on, removing the excess with a trowel. Burnish when “in love” slightly to have an authentic mineral look.



1 or 2 days later apply an optional coat of **NEUTRAL** or **PEARLESCENT WAX** using trowel or rag from wet to dry. Polish with “wooly” when dry after 1 or 2 hours. Note: waxing eliminates the mineral look of stone, but adds protection and depth.